

TN0078E [NVE] Ports List which NVE uses.doc

Latest review: 2007-6-27

Revision: A

Applies to: NVE

Level: Public

Summary

This article describes the ports list which NVE uses.

Detailed Information

Protocol	Transport Layer Protocol	Num.	Default Port	Configurable	Remarks
RTSP	TCP	1 ~ 4	554 ~ 557	YES	
HTTP	TCP	1	80	YES	
RTP	TCP/UDP	1 ~ 4	Variable	No	RTSP port is used if the protocol is TCP.
RTCP	TCP/UDP	1 ~ 4	RTP+1	No	RTSP port is used if the protocol is TCP.
Telnet	TCP	1	23	No	
Update	TCP	1	4010	No	Firmware, ActiveX, Web page
Setting	TCP	1	4004	No	Network setting, Reboot, etc... Ctrl operation
MDNS	UDP	1	5353	No	IPAdminTool uses it for searching NVE/IPC devices.

Revision History

Revision	Date	Description
A	2007-6-27	Created.
B	2007-06-29	Changed Inscriptions in Configuration of table.